




PR Series Bipolar Motors

Wiring Diagram and Rotation Chart



Step	A	C	B	D
1	+		+	
2		+	+	
3		+		+
4	+			+

CW* (downward arrow) and CCW* (upward arrow) are indicated on the left and right sides of the table respectively.

*From the flange end